

# **SIEMENS**

## **SIMODRIVE 611 analog**

Description

10.2000 Edition

### **Start-up Software for Main Spindle and Induction Motor Modules Version 3.20**

## Overview of Documentation for SIMODRIVE 611 analog

### General Documentation




Catalog  
Order Document NC 60




Catalog  
Accessories and Equip-  
ment for Special-Purpose  
Machines  
Order Document NC Z

### Manufacturer/Service Documentation




Planning Guide  
Motors  
AC Motors for  
Feed and Main  
Spindle Drives




Planning Guide  
Transistor PWM  
Inverters for AC Feed  
Drives and AC Main  
Spindle Drives



EMV Guidelines  
for  
SINUMERIK  
and  
SIROTEC  
Controls




Description  
SIMODRIVE 611 analog  
Start-up Software for  
Main Spindle and  
Induction Motor Modules



Start-up Guide  
SIMODRIVE 611 analog  
Transistor PWM  
Inverters for AC Feed  
Drives and AC Main  
Spindle Drives

### Electronic Documentation



DOC ON CD  
The SINUMERIK System

# SIEMENS

## SIMODRIVE 611 analog

### Start-up Software for Main Spindle and Induction Motor Modules Version 3.20

#### Description

#### Valid for

*Drive system*

SIMODRIVE 611 analog

Main Spindle Control

6SN1121-0BA1□-0AA□

Induction Motor Control

6SN1122-0BA1□-0AA□

10.00 Edition

Instructions for Use	1
Installation	2
Operator Control	3
Drive Initialization	4
Motor Data	5
Editing Parameters	6
Downloading the Firmware	7
Import, Start-up V1.x	8
Attachment	A

# SIMODRIVE® documentation

## Edition coding

Brief details of this Edition and previous editions are listed below.

The status of each Edition is shown by the code in the "Remarks" column.

*Status code in the "Remarks" column:*

**A** . . . . . New documentation.

**B** . . . . . Unrevised reprint with new Order No.

**C** . . . . . Revised Edition with new status.

If factual changes have been made on the page since the last edition, this is indicated by a new Edition coding in the header on that page.

Edition	Order No.	Remarks
12.93	6SN1197-0AA30-0BP0	<b>C</b>
10.00	6SN1197-0AA30-0BP1	<b>C</b>

This Manual is also included in the documentation on CD-ROM (**DOCONCD**)

Edition	Order No.	Remarks
10.00	6FC5298-6CA00-0BG0	<b>C</b>

## Trademarks

SIMATIC®, SIMATIC HMI®, SIMATIC NET®, SIROTEC®, SINUMERIK® and SIMODRIVE® are registered trademarks of Siemens. Other names in this publication might be trademarks whose use by a third party for his own purposes may violate the rights of the registered holder.

You will find additional information in the Internet under:  
<http://www.ad.siemens.de/simodrive>

This document was generated with Interleaf V 7

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

© Siemens AG 1993, 2000. All rights reserved.

Functions may be executable in the control but are not described in this documentation. No claims can be made on these functions if included with a new shipment or when involved with service.

We have checked the contents of this document to ensure that they coincide with the described hardware and software. The information in this document is regularly checked and necessary corrections are included in reprints. We are thankful for any recommendations for improvement.

Subject to change without prior notice.

# Foreword

This document is part of the documentation developed for SIMODRIVE. All documents are available individually.

The documentation list, which includes all advertising Brochures, Catalogs, Overviews, Short Descriptions, User Manuals and Technical Descriptions can be obtained from your local Siemens office with Order No., location and price.

This Manual does not purport to cover all details or variations in equipment, nor to provide for every possible contingency to be met in connection with installation, operation or maintenance.

Should further information be desired or should particular problems arise, which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the local Siemens sales office.

The contents of this Guide shall not become part of nor modify any prior or existing agreement, commitment or relationship.

The sales contract contains the entire obligation of Siemens. Any statements contained herein neither create new warranties nor modify the existing warranty.

## Definitions

### Qualified personnel

For the purpose of this documentation and product labels, a “qualified person” is someone who is familiar with the installation, mounting, start-up and operation of the equipment and the hazards involved. He or she must have the following qualifications:

- Trained and authorized to energize, de-energize, clear, ground and tag circuits and equipment in accordance with established safety procedures.
- Trained in the proper care and use of protective equipment in accordance with established safety procedures.
- Trained in rendering first aid



### Danger

This symbol indicates that death, severe personal injury or substantial property damage **will** result if proper precautions are not taken.



### Warning

This symbol indicates that death, severe personal injury or property damage **can** result if proper precautions are not taken.



### Caution

This warning (with warning triangle) indicates that minor personal injury **can** result if proper precautions are not taken.

### Caution

This warning (without warning triangle) indicates that material damage **can** result if proper precautions are not taken.

### Notice

This warning indicates that an undesirable situation or condition **can** occur if the appropriate instructions/information are not observed.



### Important

This symbol appears in the documentation if a particular issue is significant.

---

**Note**

For the purpose of this documentation, "Note" indicates information about the product or the respective part of the document which is essential to highlight.

---



---

**Warning**

Operational electrical equipment has parts and components which are at hazardous voltage levels.

Incorrect handling of these units, i.e. not observing the warning information, can therefore lead to death, severe bodily injury or significant material damage.

Only appropriately qualified personnel may commission/start-up this equipment.

This personnel must have in-depth knowledge regarding all of the warning information and service measures according to this Description.

Perfect, safe and reliable operation of this equipment assumes that it has been professionally transported, stored, mounted and installed as well as careful operator control and service.

Hazardous axis motion can occur when working with the equipment.

---

---

**Note**

It is not permissible to connect SIMODRIVE equipment to a supply system with ELCBs (this restriction is permitted acc. to DIN VDE 0160/05.88, Section 6.5). When operational, protection against direct contact is provided in a form to allow the unit to be used in enclosed electrical equipment rooms (DIN VDE 0558 Part 1/07.87, Section 5.4.3.2.4).

In compliance with DIN VDE 0160/05.88, all SIMODRIVE units are subject to a high-voltage test at the time of routine testing. If the electrical equipment of industrial tools is subject to a high-voltage test, all connections must be disconnected so that sensitive electronic components in the SIMODRIVE converter are not damaged (permissible acc. to DIN VDE 0113/06.93, Part 1, Section 20.4).

---



---

**Warning**

Start-up/commissioning is absolutely prohibited until it has been ensured that the machine in which the components described here are to be installed, fulfills the regulations/specifications of the Directive 89/392/EWG.

---



### Warning

The information and instructions in all of the documentation supplied and any other instructions must always be observed to eliminate hazardous situations and damage.

- For special versions of the machines and equipment, the information in the associated catalogs and quotations applies.
- Further, all of the relevant national, local and plant/system-specific regulations and specifications must be taken into account.
- All work should be undertaken with the system in a no-voltage condition!

## ESDS information

### Electro-static discharge sensitive devices



Components which can be destroyed by electrostatic discharge are individual components, integrated circuits, or boards, which when handled, tested or transported, could be destroyed by electrostatic fields or electrostatic discharge. These components are designated as **ESDS (ElectroStatic Discharge Sensitive Devices)**.

Handling ESDS boards:

- The human body, working area and packing should be well grounded when handling ESDS components!
- Electronic boards should only be touched when absolutely necessary.
- Components may only be touched, if
  - you are continuously grounded through an ESDS bracelet,
  - you are wearing ESDS shoes or ESDS shoe grounding strips in conjunction with an ESDS floor surface.
- Boards may only be placed on conductive surfaces (desk with ESDS surface, conductive ESDS foam rubber, ESDS packing bag, ESDS transport containers).
- Boards may not be brought close to data terminals, monitors or television sets (a minimum of 10 cm should be kept between the board and the screen).
- Boards may not be brought into contact with materials which can be charged-up and which are highly insulating.
- Measuring work may only be carried out on the boards, if
  - the measuring equipment is grounded (e.g. via the protective conductor) or
  - for floating measuring equipment, the probe is briefly discharged before making measurements (e.g. a bare control housing is touched).
- Only touch the control boards at the front panel

## Further information

Additional detailed information is provided in the Planning Guides and Start-up Guides of our products.



# Contents

<b>1</b>	<b>Instructions for Use .....</b>	<b>1-1</b>
<b>2</b>	<b>Installation .....</b>	<b>2-3</b>
2.1	System requirements .....	2-3
2.2	Installation .....	2-4
2.3	Starting the program .....	2-5
2.4	Exiting the program .....	2-5
<b>3</b>	<b>Operator Control .....</b>	<b>3-7</b>
3.1	General operator control .....	3-7
3.2	Program structure .....	3-10
3.3	Program settings .....	3-11
3.4	Resetting the password .....	3-13
<b>4</b>	<b>Drive Initialization .....</b>	<b>4-15</b>
<b>5</b>	<b>Motor Data .....</b>	<b>5-17</b>
5.1	Motor data .....	5-17
<b>6</b>	<b>Editing Parameters .....</b>	<b>6-21</b>
6.1	File functions .....	6-21
6.2	Editing data ONLINE .....	6-23
6.3	Editing data OFFLINE .....	6-25
6.4	User pages .....	6-26
<b>7</b>	<b>Downloading the Firmware .....</b>	<b>7-29</b>
<b>8</b>	<b>Import, Start-up V1.x .....</b>	<b>8-31</b>
<b>9</b>	<b>Attachment .....</b>	<b>A-33</b>
A.1	File structure .....	A-33
A.2	File formats .....	A-35
A.3	Connecting cable from the drive converter to computer .....	A-37
A.3.1	9/25 pin .....	A-37
A.3.2	9/9 pin .....	A-38
A.4	Keyboard labeling at the PC .....	A-39

## Space for your notes

[illegible]

# Instructions for Use

# 1

## Application

The start-up software IBS V3.x (6SN1153-2AX10-0A□□) is used to service and start-up (commission) the SIMODRIVE 611 analog main spindle drives (MSD) and induction motor modules (IMM).



### Danger

When using this start-up software with a SIMODRIVE drive converter module, the operator control and warning information and instructions in the documentation (Start-up Guide, Planning Guide) of the associated drive converter module must be observed.

The user can process parameters online in the drive converter or offline in a file. The drive converter-specific parameters are displayed arranged according to logical groups; each parameter has a brief description. Data sets can be transferred, as required between the drive converter and start-up software. The saved parameter settings can be transferred from a file into the drive converter, which simplifies series start-up of drives.

## Transferring old parameter sets

Parameter settings (sets), generated with the IBS V1.x program, can be transferred to IBS > V2.0 and further processed.

## Firmware update

The firmware release of the drive converter can be updated by transferring special files. No changes have to be made to the drive converter hardware.



### Danger

If enable signals have been output to the SIMODRIVE drive converter module, but the drive does not rotate, then the **Operating display** function should be used to check whether there is a fault.





## 2.1 System requirements

### Hardware requirements

The start-up software Version 3.20 requires the following hardware platform:

- IBM® AT-compatible computer
- 640 kbyte main memory, of which, at least 400 kbyte of memory for programs
- Floppy disk drive
- Hard disk, with min. 2 Mbyte free memory
- Black and white monitor
- Keyboard
- Serial interface
- Connecting cable to establish a link from the drive converter to computer (refer to the Attachment)

### Optional hardware

In addition to these minimum requirements, the following can be optionally used:

- Mouse
- Color monitor
- Printer

### Software requirements

Software configuration for IBS V3.20

- MS-DOS® operating system, from version 3.0.
- Equipment driver ANSI.SYS (or an equivalent for the graphics card used).
- Codepage 437 must be set (refer to the MS-DOS Manual, using code pages)
- Mouse driver if a mouse is to be used (refer to the Mouse Manual).
- Interface driver, if interfaces COM3: and COM4: are to be used (refer to the Computer Manual, Manual on the Interface Module).
- We recommend a disk cache program (e. g. SMARTDRIVE) in order to accelerate the program processing (especially when displays are being built-up).

## 2.2 Installation

Proceed as follows to install the software:

### Prerequisite

Please ensure that the ANSI.SYS driver is loaded (generally, the CONFIG.SYS file contains an entry with the following syntax:

under DOS: DEVICE = C:\DOS\ANSI.SYS

under Win 95/98: DEVICE = C:\WIN.95\COMMAND\ANSI.SYS

### Calling

Insert the installation floppy disk and start the installation program. If the floppy disk is inserted in drive A: then the following must be entered:

**C>A:**

**A>INSTALL language version**

The installation program prompts you to enter all of the other entries in the user dialog box.

### Operator control

The following applies for all screen masks:

RETURN           all of the entries in the current mask are confirmed as being valid, installation is continued.

CTRL-C           interrupts the installation program.

The program can be immediately started after it has been installed. The **Program settings** function, which is part of the start-up software, can be used to optimally adapt the software to the computer being used.

## 2.3 Starting the program

### Program call

To start the program, the required drive converter type is specified as parameter in the command line.

The call is as follows:

**IBS 611HSA** [/M] for the SIMODRIVE 611 analog MSD drive converter

**IBS 611AMM** [/M] for the SIMODRIVE 611 analog induction motor module drive converter

Mouse support can be selected using parameter /M. In this case, the associated mouse driver must be installed and activated (refer to the mouse documentation).

### Selecting the drive converter firmware release

The actual program settings are displayed in the basic display (refer to Section 3.2, Program structure). The firmware release for the drive converter data to be processed, must be selected here.

## 2.4 Exiting the program

The start-up program is exited and you return to the DOS level by pressing soft-key F7 in the basic display.



[illegible]

# Operator Control

# 3

## 3.1 General operator control

### Operator control philosophy

The IBS (start-up) program handling from V2.0, is, as far as possible, based on handling SINUMERIK 840C . This means that all of the functions are selected using softkeys.




Fig. 3-1 General handling

You can return to the higher-level menus with RCL; the menu bar is, when required, extended horizontally using ETC.

Supplementary functions, which do not contain any menu branching, are located in the vertical menu bar.

**Keyboard**

The softkeys are actuated using the following keys:

Table 3-1 Keyboard assignment

Key	Softkey horizontal	Key	Softkey vertical
ESC	RCL		
F1	Softkey 1	SHIFT + F1	Softkey 1
F2	Softkey 2	SHIFT + F2	Softkey 2
F3	Softkey 3	SHIFT + F3	Softkey 3
F4	Softkey 4	SHIFT + F4	Softkey 4
F5	Softkey 5	SHIFT + F5	Softkey 5
F6	Softkey 6	SHIFT + F6	Softkey 6
F7	Softkey 7	SHIFT + F7	Softkey 7
F8	ETC		

**Help**

A brief help text can be called in each menu using key F10.

**Mouse**

If the program was started with the /M option, the softkeys can be actuated using the mouse (lefthand mouse key).

**Dialog boxes**

Dialog boxes are used for additional entries as well as program messages.




Fig. 3-2 Example of a dialog box

In this case, the following applies:

RETURN selects the **OK** button.

ESC selects the **Exit** button.

The buttons can be alternatively selected using the mouse.

As long as a dialog box is active, no other functions can be executed. If several input fields are available in a dialog box, then you can toggle between the individual fields using the TAB key.

**Program disable**

The IBS V2.0 program can be temporarily disabled. After you press the **CTRL-S** key combination, you will be prompted to enter the system password. After entering **1111**, the PC with start-up program is disabled for additional entries. The program can only be re-enabled by re-entering the system password.

## 3.2 Program structure

<b>SIMODRIVE Start-up Software Version 2.0</b> <b>Copyright (C) Siemens AG 1993 All Rights Reserved</b>						F1 Program settings
Converter: 611-A HSA      Firmware release : 1.00						F2
Settings Converter interface : COM1: Printer: LPT1 63 Lines/page						F3 Reset password
						F4
						F5
						F6
						F7
F1 Edit parameters	F2 Initialize drive	F3 Motor data	F4 Download firmware	F5	F6 Import IBS V1.x	F7 Exit program

Fig. 3-3 Basic display

This display provides an approximate overview of the program structure. The individual functions are described in the following sections of these instructions.

## 3.3 Program settings

The start-up program settings are made here. All of the selected settings are saved and are re-activated the next time that the program is started.

### Selecting the firm-ware release

Select the actual firmware release of your SIMODRIVE drive from the list.

IBS 611IMM supports the versions:	1.3
	2.0
	2.1
	3.1
IBS 611MSD supports the versions:	2.1
	2.2
	2.3
	2.4
	3.0
	3.1

---

#### Note

In order to be able to communicate with all firmware releases, you must use the latest start-up software.

---

### Handling

You can toggle between the individual areas and possible settings using the TAB and SHIFT-TAB keys. A selection is made within a particular field using CURSOR-UP and CURSOR-DOWN. The required elements can also be directly selected using the mouse.

## 3.3 Program settings

**Program settings**

**System language**

German  
English  
French

**Interface**

(\*) COM1:  
( ) COM2:  
( ) COM3:  
( ) COM4:

**Names**

(\*) SIEMENS  
( ) Kunde

**Printer :**

(\*) LPT1: File name : [ ]  
( ) LPT2:  
( ) LPT3: Lines/page [ 63]  
( ) File :

**Color**

(\*) Black/white  
( ) Color

< OK > < Cancel > < Help >

Fig. 3-4 Program settings

The individual fields mean:

**System language**

Language in which the start-up program runs.

**Interface**

Selects the interface for the link between the PC and drive converter. Generally, the COM3: and COM4: interfaces can only be used after the computer has additional hardware and software upgrades. A description of the cable to couple the PC to the drive converter is provided in the Attachment.

**Printer**

Selects the parallel interface to which the printer is connected. If the printer is routed to a file (a file is selected and any file name is entered, possibly with drive and directory), then only the last print task is saved in the specified file.

**Lines/page**

Defines the number of lines before a page feed is made.

**Designations**

The parameters are shown as standard with the parameter descriptions, specified by SIEMENS AG. If other names are required, an appropriate file must be generated (refer to the Attachment for the file format). After selecting "Customer", all of the parameter descriptions will appear with the required names. If you use your own description file, this means that the appropriate files for *all* drive converters and *all* software releases must be created. SIEMENS AG assumes no guarantee that the start-up software will correctly function with modified parameter descriptions (also refer to the Section, File formats).

**Color**

Selects whether the program has color or black and white displays. For portable computers with LCD screens, black and white generally makes the screen easier to read.

## 3.4 Resetting the password

### Password protection, drive converter parameters



The system password must first be entered before parameters can be directly changed in the drive converter. To change a parameter in the drive converter for the first time in the online mode, the user must enter the system password (1111).

---

#### Warning

After the password has been entered, all of the drive converter parameters can be changed. The write protection in the drive converter module is disabled.

---

After having made the required changes, or when leaving the work station, we recommend that write protection is re-enabled by pressing the **Reset password** softkey.





# Drive Initialization

# 4

Every drive converter module must be initialized when it is first started-up. All of the drive converter parameters are pre-assigned with factory standard values. This program branch requires that an ONLINE connection is established to the SIMODRIVE drive converter.

Initialize drive 611-A HSA 1.00

**First drive initialization**

Power module number-motor measuring [ 7 ]  
 Motor code number [ 101 ]  
 Encoder pulse number-motor measuring system [ 2048 ]

F1 F2 F3 F4 F5 F6 F7 Initialize

Fig. 4-1 Drive initialization

## Data to be entered

Data must be entered to initialize the drive (also refer to the Start-up Instructions of the drive converter module involved)

For 611 analog MSD:

Power module code number<sup>1)</sup>

Motor code number

Encoder pulse number – motor measuring system

For 611 analog IMM:

Power module code number<sup>1)</sup>

Motor code number (4 sub-parameters) has presently not been implemented

1) Power modules with Order No. [MLFB] 6SN112□-1A□□□-□□A1, are automatically recognized from FW 3.00 onwards. In this case, it is not necessary to enter the power module code number.

If a complete file is to be downloaded into the drive converter after initialization, only the power module code number has to be entered (refer to **Loading from the hard disk**).

### Initialize softkey

The actual initialization operation is started by pressing the **Initialize** softkey. If the drive converter has fault messages, these are immediately read-out and displayed after initialization has been completed. If the drive converter module has already been initialized, a warning note is displayed but initialization can be forced by acknowledging.



---

#### Warning

The **Initialize** function overwrites all of the parameters which have been changed in the drive converter module.

---



# Motor Data

## 5.1 Motor data

When initializing, standard Siemens (Catalog) motors are parameterized by entering a code number (presently, only MSD). If other non-catalog motors are connected to the drive converter module to be parameterized, then the necessary parameters can be entered here. This program branch requires that an ONLINE connection has been established to the SIMODRIVE drive converter.

### Configuration, 611 analog MSD

For 611 analog main spindle drive (MSD), the following configurations are possible:

- A third-party motor (key F1)
- A third-party motor with star-delta changeover (key F2 for the star data set, F3 for the delta data set)
- Two catalog motors (code number for motor 1 is specified when initializing, code number for motor 2, using key F4)
- Two third-party motors without star-delta changeover (key F1 for the 1st motor, F5 for the 2nd motor)

Load motor

611-A HSA 1.00

Motor code number 1101

Motor code number 2101

F1

F2

F3

F4

F5

F6

Operating display

F7

Read fault message

F1	F2	F3	F4	F5	F6	F7
▲ 1st non-catalog motor	Star data	Delta data	2nd catalog motor	2nd non-catalog motor		Save

Fig. 5-1 Load motor, 611 analog MSD selection

The specified configurations cannot be mixed, as, in some cases access is made to the same parameters. Depending on the particular configuration, only the required data set has to be selected for editing.

Stern-Daten		Rated motor output Rated motor current		611-A HSA 1.00		F1
P159	Motor moment of inertia	#	0.011 kgm <sup>2</sup>			F2
P160	Rated motor output	#	3.7 kW			F3
P161	Rated motor current	#	12.5 A			F4
P162	Rated motor voltage	#	268.0 V			F5
P163	Rated motor speed	#	1500 RPM			F6
P164	Rated motor frequency	#	53.0 Hz			Operating display
P165	No-load motor voltage	#	235.0 V			F7
P166	No-load motor current	#	6.2 A			Read fault message
P167	Stator resistance, cold	#	735 mOhm			
P168	Rotor resistance, cold	#	510 mOhm			
P169	Stator leakage reactance	#	1187 mOhm			
P170	Rotor leakage reactance	#	1608 mOhm			
P171	Magnetizing reactance	#	22870 mOhm			
P172	Upper speed Xh characteristic	#	3100 RPM			
P173	Speed at the start of field weakening	#	2375 RPM			
P174	Max. motor speed	#	9000 RPM			
F1	F2	F3	F4	F5	F6	F7
▲						Calculate data

Fig. 5-2 Load motor, 611-A MSD star data

## Handling

The parameters must then be supplied with the required values. The parameters are edited as described under **Edit parameters**. After all of the values have been entered as required, the necessary conversions are initiated by pressing the **Calculate data** softkey. The conversion only runs in the drive converter when the controller and pulses are inhibited.

## Erroneous motor data

Calculation errors can occur for incorrectly selected values when converting (message: Fault messages present). In this case, parameterization and calculation must be repeated with corrected values.



### Danger

The drive could be destroyed when attempting to commission it with erroneous motor data.

**Configuration,  
611 analog IMM**

Up to four motors can be connected to the 611 analog IMM.

Load motor		611-A AMM 1.00		F1		
				F2		
Motor code number 1		0		F3		
Motor code number 2		0		F4		
Motor code number 3		0		F5		
Motor code number 4		0		F6		
				F7		
				Operating display		
				Read fault message		
F1	F2	F3	F4	F5	F6	F7
▲Motor 1	Motor 2	Motor 3	Motor 4			Save

Fig. 5-3 Load motor, 611 analog IMM selection

In this case, the rating plate data and equivalent circuit diagram data must be specified for each connected motor. The equivalent diagram data can be alternatively calculated from the rating plate data. The calculations can only be made with the controller and pulses inhibited.

**Note**

Presently, motor code numbers are not implemented in the drive converter.



# Editing Parameters

# 6

## 6.1 File functions

All of the functions to edit drive converter parameters can be selected in this mask.




Fig. 6-1 File functions

### File selection

All of the files, generated for the selected drive converter type and all of the directories and drives of the computer are displayed in the file list. In addition, the <ONLINE> entry appears where direct online editing is selected in the drive converter.

Items from the file list are selected using the cursor keys and the softkey of the required function (the RETURN key has the same significance as the **Edit** softkey). The required entries can be directly selected using the mouse (a double click corresponds to selecting using **Edit**). For directories and drives, the contents are displayed after RETURN or a double click.

## 6.1 File functions

<b>Edit</b>	Drive converter parameters are edited OFFLINE in the file or ONLINE in the drive converter.
<b>Edit, new offline</b>	A new file is created in the current directory.
<b>Delete</b>	The selected file is deleted.
<b>Saving to hard disk</b>	All of the parameters are read-out of the drive converter and saved under specified file names.
<b>Load from hard disk</b>	<p>The selected file is downloaded into the drive converter.</p> <p>If the file was generated for an older firmware release of the drive converter, a message is output. However, the selected file can still be downloaded after acknowledgement.</p> <p>A plausability check is made while the data is being downloaded. Erroneous values can be immediately and inter-actively corrected. However, the correction is only made in the drive converter itself.</p> <p>In order to guarantee data consistency, after corrections have been made, or if the drive converter has a different firmware release, the <b>Save to hard disk</b> function must be executed.</p> <p>While a file is being downloaded, the drive converter pulses are inhibited. This inhibit can only be removed <i>after successful data transfer</i>. If data transfer is unintentionally interrupted, the drive converter has to be powered-down and up again before it goes into the ready condition.</p> <p>Parameter files can only be downloaded for drive converter which have already been initialized. For safety reasons, the power module code number P095 cannot be overwritten. This means, that this must have already been entered when initializing. The other parameters, selected when initializing – for main spindle drives, motor code number P096 and encoder pulse number motor – measuring system P098 – can be overwritten by the appropriate values in the parameter file.</p>
<b>Print protocol</b>	The selected file is printed. Service support is possible by calling the function for the <ONLINE> entry. In this case, the <i>actual drive converter status</i> (including the display parameters) is listed.
<b>Comparison</b>	<p>The selected file is compared with the data in the drive converter module.</p> <p>Different parameters are displayed. Only the parameters saved in the file are used for comparison.</p> <p>The function is exited if the comparison results in more than 300 differences.</p>

## 6.2 Editing data ONLINE

### Parameter display

The parameters are grouped according to functions. The first line contains the presently selected function group.

The parameter number is located to the left (Pxxx).

For gearbox stage or motor-dependent parameters, the sub-parameter number (:y) is additionally specified.

If only individual bits of a parameter are displayed, bit numbers (0 to 15) are specified (.z). A brief description is provided next to the parameter number. Parameters, which can only be changed in specific statuses, are designated as follows:

- ! Parameter is write protected
- # Motor data parameters (only MSD). <sup>1)</sup>
- \$ Parameter can only be changed when initializing <sup>2)</sup>

The particular parameter value and parameter units follow.

### Status displays

The status line (first line) of the display indicates which parameter group has presently been selected for editing. <ONLINE> is displayed in the second line, OFFLINE the file name or a reference to possible drive converter faults.

Motor/power module data						611-A HSA	1.00	F1
Fault message is present !								Value +
								F2
								Value -
								F3
								Search
								F4
								F5
								Save
								F6
								Operating display
								F7
								Read fault message
F1	F2	F3	F4	F5	F6	F7		
▲ Motor/power module	Monitor limit	Message data	Measuring system inputs	Controller data	Diagnostics data			
F1	F2	F3	F4	F5	F6	F7		
▲ User side 1	User side 2	User side 3	User side 4	User side 5	User side 6	User side 7 ▶		

1st line  
2nd line

F8

Fig. 6-2 Example, ONLINE editing

- 1) Changes made to these parameters only become effective after conversion in the drive converter. This conversion is started in the **Motor data** parameter group. Motor data should only be entered and changed there.
- 2) This parameter is entered in the **Initialize drive** parameter group.

## Change parameters

When editing drive converter parameters, a differentiation is made between a display and an edit mode. Depending on which mode is active, different operator actions are possible.

Table 6-1 Parameter editing mode

Display mode	Edit mode
The parameters are cyclically read-out of the drive converter you can scroll as required within the parameters	The selected parameter can be changed
Change-over into the edit mode (if the selected parameter is not write protected): <b>Number:</b> The old value is overwritten <b>RETURN:</b> The old value is kept, it can be edited <b>←,→:</b> The value is changed-over for bit fields	Return to the display mode (if the entered value is correct): <b>RETURN:</b> The visible value is accepted and formatted <b>ESC:</b> The current parameter editing is cancelled, the old value is restored.

## Operator control

Cursor keys can be used to scroll within the pages; softkeys can be used to change between the individual pages. For gearbox-stage dependent parameters (for IMM, also motor-dependent parameters), only the parameters of the first two stages or motors are displayed in the actual mask. All of the sub-parameters associated with the actual parameter are displayed by again pressing on the softkey to select the actual mask. If the softkey is pressed again, the original display is re-selected.

**In addition, the following special functions are available in the online mode at the vertical softkeys:**

### Value +

Increments the selected parameter value.

### Value –

Decrements the selected parameter value.

### Search

Searches for a specific parameter number. A search is made from the current position up to the end of the page, from the beginning of the page up to the cursor position and in all pre-defined pages. The position is jumped-to when the parameter number is found.

### Save

The actual parameter values are saved in an FEPRM in the drive converter.

### Operating display

Displays the actual drive converter status.

### Read fault message

Reads-out faults from the drive converter.

## 6.3 Editing data OFFLINE

### Differences with respect to ONLINE editing

Editing parameters offline in a file corresponds to editing parameters online. The second line of the display shows the name of the file presently being worked-on.

Values, which have still not been entered, are designated by a \* . Only the edited values are entered in the file (values with \* are not saved).

When creating parameter files offline, the values which are entered are not checked to ensure that they are within a valid value range. This is only done when the file is downloaded into the drive converter. This means, that corrections may be necessary when downloading the file.

Parameters which were not saved, are not changed when they are transferred to the drive converter. This means that several files can be downloaded with parameter values.

The **Value +**, **Value -**, **Operating display** and **Read fault message** functions are not available when editing offline.

### Entering motor data

When editing the motor data parameters, marked with # , offline (only 611-A MSD), the following should be observed:

- Parameter file for a catalog motor: The motor code number is specified in P096.  
Motor data P159 to P175 and P219 to P235 are automatically determined in the drive converter, and do not have to be specified in the file. For a motor with star-delta changeover, the motor code number of the delta data set must also be saved in P238.
- Parameter file for a third-party motor: 99 must be entered as motor code into P096.  
Motor data P159 to P175 must be entered in the file. For motors with star-delta changeover, the appropriate delta data set must be entered in P219 to P235 and P238 should be set to 99.

In both of these cases, parameter calculations which are necessary, are automatically carried-out after the data has been downloaded into the drive converter.

## 6.4 User pages

In addition to the permanently specified parameter segmentation on various pages, seven dedicated pages with any parameters can be defined. This means that you can define parameters which you require for service and commissioning purposes.

The page **User 1** is pre-assigned, as standard with a list of all of the parameters in an increasing consecutive order. Pages **Users 2 to 7** remain empty. All of the user pages can be modified using the **Edit user** function. The page definitions are saved on the hard disk, and can be re-used the next time that the program is started.

User side 2		611-A HSA 1.00		F1	
<ONLINE>				Value +	
Test, controller settings				F2	
P001	Speed setpoint	!	300 RPM	Value -	
P002	Speed actual value	!	120 RPM	F3	
P031:1	P gain, speed controller		32.0	Search	
P032:1	Integral action time, speed controller		20 ms	F4	
				Edit user	
				F5	
				Save	
				F6	
				Operating display	
				F7	
				Read fault message	
F1	F2	F3	F4	F5	F6
▲ User side 1	User side 2	User side 3	User side 4	User side 5	User side 6
					User side 7 ►

Fig. 6-3 Example, user page

### User pages 2 to 7

When a user page is being generated, only the required parameter numbers have to be entered. The associated descriptive texts are automatically determined. Empty lines and titles can also be entered. Parameter numbers must be precisely specified as in the parameter description. This means that gearbox-stage-dependent parameters (for IMM, also motor-dependent parameters), must be entered with the required gearbox stage or motor.




Fig. 6-4 Configuring for Fig. 6-3, example, user page

## Displays

After re-selecting parameter editing (by pressing the **OK** softkey), the edited page is immediately filled with the current parameter values. When an attempt is made to access an unknown parameter, **???** is displayed for the parameter description. If the required parameter is signaled as being unknown, a check should be made as to whether the sub-parameters were correctly specified.



[illegible]

# Downloading the Firmware

## Firmware retrofit

The SIMODRIVE 611 analog MSD and IMM drive converter modules are supplied from the factory with the current firmware release. If a user requires, e.g. an older firmware release, or if already supplied modules have to be upgraded to the current firmware release then this can be realized using the **Download firmware** function downloaded into the drive converter. The firmware is automatically saved in the drive converter in an FEPROM.

The firmware releases can be ordered from SIEMENS AG.

---

### Note

Firmware FW3.□□ does not run on the 6SN1121-0BA1□-0AA0 or 6SN1122-0BA1□-0AA0 control.

Firmware FW2.□□ only conditionally, on the new hardware 6SN1121-0BA1□-0AA1 and 6SN1122-0BA1□-0AA1.

---

## Preparation

The files which are supplied must be copied—over according to the attached instructions, refer to the Installation Guide, Section 2.2. The **Download firmware** function can then be started.




---

### Warning

The **Download firmware** function deletes all of the data in the drive converter module.

---

Before the function is started, the user is prompted to acknowledge again. The current firmware release of the drive converter is displayed for checking purposes.




---

### Warning

If the **Download firmware** function is interrupted (power off, the connection is disconnected), the drive converter module can be damaged.

---

## Completing the download

After the new firmware release has been successfully downloaded, the system must be initialized. The drive converter module can then be parameterized. ■

## Space for your notes

[illegible]

## Import, Start-up V1.x

The IBS V3.20 program allows old parameter files, generated with release 1.x, to be transferred. This allows parameter settings, which were generated for 611 MSD and IMM to also be used for 611 analog drive converters, MSD and IMM.

### Conversions

The import function conditions the parameters so that the values can be directly downloaded into a 611 analog module with firmware release 1.1. If 611 parameters have to be converted to 611 analog, this is realized automatically.

### Files required

This function requires the data file of the IBS V1.x program (\* .P11/\* .P1A) as well as the associated attribute file, in the same directory (\* .ATT).

### Replacing modules

When replacing a SIMODRIVE 611 module by a SIMODRIVE 611 analog module, proceed as follows:

- Save the actual parameter settings of the module to be replaced in a parameter file using the start-up software IBS V1.x. The parameter attributes must also be saved (IBS V1.x prompts you to do this when the program starts).
- Import the generated files using the IBS >V2.0 start-up program.
- Initialize the SIMODRIVE 611 analog module. Only the power module code number P095 must be entered (refer to **Downloading from the hard disk**).
- Download the newly generated parameter file into the SIMODRIVE 611 analog module (**Load from hard disk** function).
- For IMM, initiate the automatic offset adjustment of the power sensing for all motor data sets

Table 8-1 Restrictions for the imported files

611 MSD up to Version 4.0 from Version 5.0	None HPC axis function for 611 analog has still not been implemented
611 IMM	None



## Space for your notes

[illegible]

# Attachment

# A

## A.1 File structure

### File extensions

<b>System files</b>	611-A MSD:	*.1PH
	611-A IMM:	*.1PA
<b>User files</b>	611-A MSD:	*.1AH
	611-A IMM:	*.1AA

# A

## A.1 File structure




Fig. A-1 File structure

## A.2 File formats



### Warning

The following section describes the internal structure of the files which are used. Any manipulation could cause the start-up software to crash.

### Parameter description (files: PB?????.1PH / PB?????.1PA)

#### Structure:

Pxxx[:y][.z] description, units active, format code  
supplement

Pxxx[:y][.z]      Parameter number with optional sub-parameter and bit access.  
All of the parameter numbers must be sorted in an increasing sequence.  
When accessing bits, the parameters must be listed once with the full format

Description      Descriptive text (max. 34 characters, in " ")

Units              Units text (max. 9 characters, in " ")

Active             ID when the parameter is active  
0   immediately  
1   after conversion  
2   when intializing  
16   write protection

Format key        Coding for parameter format  
1   4-character word, hexadecimal  
5   unsigned word, decimal  
7   signed word, decimal  
11   signed float, 1 decimal place  
:  
13   signed float, 3 decimal places  
21   unsigned float, 1 decimal place  
:  
23   unsigned float, 3 decimal places  
50   bit toggle

Supplement       Toggle codes for format key 5

In order to generate parameter descriptions with customer-specific texts, the files supplied must be copied from the required source language into Catalog X, and then modified as required.



### Warning

SIEMENS AG accepts no liability for any damage arising due to modified files.

### Parameter values (files: \*.1AH / \*.1AA)


Structure:	UmTyp FW Pxxx[:y]=value
UmTyp	Coding, drive converter type (1 = 611-A MSD, 2 = 611-A IMM)
FW	Drive converter firmware release
Pxxx[:y]	Parameter number with optional sub-parameter If the same parameter number is used a multiple number of times, then there is an undefined behavior when processing
Value	Parameter value

### Page description (files: SIEM???? .1PH/SIEM???? .1PA und ANW? .1PH/ANW? .1AH)

Structure:	Sx H#xxx H"text" Pxxx[:y][:z]
Sx	Page number (only for SIEMENS pages)
H#xxx	Title, text is specified coded
H"text"	Title, text is directly specified (user pages)
Pxxx[:y][:z]	Parameter number with optional sub-parameter and bit access which should be displayed

## A.3 Connecting cable from the drive converter to computer



### A.3.1 9/25 pin




A

## A.3 Connecting cable from the drive converter to computer

## A.3.2 9/9 pin

**Connector**





D-sub,  
9-pin plug  
Position: 1 below  
Housing  
6FC9348-7HT

**Connector**

D-sub,  
9-pin socket  
Position: 1 below  
Housing  
6FC9348-7HT

## A.4 Keyboard labeling at the PC

Table A-1 Keyboard labeling

The following key names are used in this description:	You might find these names on your keyboard:
RETURN	ENTER, NEXT 
BACKSPACE	BACK 
ESC	Esc, ESCAPE, input delete
INSERT	INS, Ins, line+
DELETE	DEL, Del, line–
SHIFT	
CTRL	Ctrl, CONT
TAB	← →   →
HOME	Home, Pos 1
END	End
PGUP	Display ↑
PGDN	Display ↓
CURSOR–UP	↑
CURSOR–DOWN	↓
ALT	Alt, special characters





To  
SIEMENS AG  
A&D MC BMS  
Postfach 3180  
D-91050 Erlangen  
(Tel. 0180 / 525 – 8008 / 5009 [Hotline]  
Fax 09131 / 98 – 1145  
email: motioncontrol.docu@erlf.siemens.de)

<p><b>From</b></p> <p>Name _____</p> <p>Company address/Dept. _____</p> <p>Street _____</p> <p>Postal code: _____ City: _____</p> <p>Telephone: _____ / _____</p> <p>Telefax: _____ / _____</p>	<p><b>Recommendations</b></p> <p><b>Corrections</b></p> <p>For documentation:</p> <p>SIMODRIVE 611 analog  Start-up Software for  Main Spindle and Induction Motor Modules  Version 3.20</p> <p>Manufacturer/Service Documentation</p> <p><b>Description</b></p> <p>Order No.: 6SN1197-0AA30-0BP1  Edition: 10.00</p> <p>If you come across printing errors in this document, please let us know using this form. We would also be grateful for any recommendations and suggestions.</p>
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Recommendations and/or corrections**